

COUNTDOWN TIMER



ECOSAVERS

EcoSavers® Countdown Timer

The EcoSavers® Countdown Timer helps you to save energy in a simple and easy way.

You can select the requested timeframes 15 minutes - 30 minutes - 1 hour - 2 hour -4 hours both for switching electricity off and on.

Want to charge the battery of your laptop knowing it will be fully charged after 1,5 hour ? Just select 2 hours countdown time (switching off) and after 2 hours the electricity will be automatically cut off.

Technical parameters:

Voltage:	230V/50HZ
Amp:	MAX 16A
Setting range:	15 minutes-30 minutes-1 hour- 2 hours -4 hours
Plug:	Schuko (type F)
Size:	120 x 55 x 80 mm
Energy use:	0,25 watt



ECOSAVERS®